



## How to Update MDS Series Software V2.0

1 Login <https://www.cnausland.com> , and Download the MDS Series Update Tool.


1.1 Select “SUPPORT & UPDATE”----“Downloads”



1.2 Click “DOWNLOAD”




1.3 Download the MDS Series Update Tool



2 Setup MDS Series Update Tool in your pc

2.1 Unzip MDS Series Update Tool and Set up it.



MDS-Series Update Client V5.0

修改日期	类型	大小
2019/1/9 17:59	应用程序	30,676 KB

MDS-Series Update Client 5.0 Installation



### Welcome to the MDS-Series Update Client Setup Wizard

This wizard will guide you through the installation of MDS-Series Update Client.

It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer.

Click Next to continue.

**Next >** Cancel




### 3 Register and Update Software

3.1 **Connect the MDS main unit to PC with USB** and Run the MDS Series Update tool.




### 3.2 Register

3.2.1 Fill out your Email and click Next




### 3.2.2 Fill out the information and Submit



### 3.3 Update Software

Select Language and car, then Download the software.



Remark:

1. if you need update all the cars, please select Update ALL.
2. If we release the latest version of the display program, first prompt to upgrade the display program, then upgrade the model software.

Any question, please contact us.

[info@cnausland.com](mailto:info@cnausland.com)